

## **H382702 WILT PENDANT**

### ASSEMBLY AND MOUNTING INSTRUCTIONS

#### **GENERAL**

- WARNING-DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. TURN OFF THE ENTIRE ELECTRICAL CIRCUIT TO WHICH THE LIGHTING FIXTURE IS ATTACHED
- INSTALLATION AND MAINTENANCE OF THIS FIXTURE SHOUILD BE COMPLETED BY A LICESNSED ELECTRICAN
- FAILURE TO INSTALL FIXTURE CORRECTLY COUD RESULT IN SEROIUS INJURY OR DEATH
- READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION.

- IF AN EXISTING FIXTURE IS BEING REPLACED, REMOVE IT AND NOTE TO WHICH WIRE IN THE OUTLET BOX THE ORIGINAL FIXTURE WAS ATTACHED.
- BEFORE DISCARDING THE CARTON DOUBLE CHECK THE PACKAGING TO MAKE SURE ALL PARTS HAVE BEEN FOUND.
- THIS FIXTURE WAS DESIGNED TO BE MOUNTED TO AN OCTAGON OUTLET BOX. THE BOX MUST BE SECURELY MOUNTED TO THE STRUCTURE OF THE BUILDING.

#### **INSTALLATION**

STEP 1.	Feed the wires through pipe stems, canopy and mounting
	plate. Twist stem tightly onto the body. Keep adding
	additional stems to you desired height.

- STEP 2. Slide in the canopy onto the stem, and thread it onto the stem.
- STEP 3. Attach the mounting plate to the outlet box by using the mounting screws.
- STEP 4. Trim excess wire to min 6" beyond the canopy, strip each wire to 5/8".
- STEP 5. Fasten bare ground wire to ground wire from the wall outlet box (usually green or copper color) or connect ground wire to green screw on the mounting plate.
- STEP 6. Connect the neutral (white) fixture wire coming from the fixture base to neutral (usually white) outlet wire. Fasten both wires together with a plastic wire nut and tightly wrap

#### the wire nut with electrical tape.

STEP 7. Repeat the previous step with the hot (black wires). Make sure there are no exposed wires or strands that could cause a dangerous short circuit.

FAILURE TO CONNECT THE APPROPRIATE WIRES CORRECTLY COULD RESULT IN SEROIUS INJURY OR DEATH!

- STEP 8. Place the canopy with the fixture over the outlet box and fasten it by the ball nuts.
- STEP 9. Install the lamp(s). The fixture is rated for 40 watt type G16.5 lamp.

DO NOT EXCEED RECOMMENDED WATTATE!

STEP 10. Restore power to the circuit at breaker or fuse-box.

#### **DIMMING**

The fixture can be controlled by a wall dimming device. Only use triac/electronic dimmer. Make sure carton is marked for use with LED compact fluorescent-incandescent light source only. These can be

provided by your local electrical distributor, home center, or hardware store.


#### **CLEANING**

Please clean with a soft, dry cloth ONLY! Do not use cleaning products.





# ASSEMBLYANDMOUNTINGDIAGRAM



## WIRE NUT/TAPINGDIAGRAM

